


Product Overview

Our sonic cleansing technology brings a new experience for healthy, glowing, and more refined skin. With 8 levels of vibration, it will effectively remove skin pollutants, impurities, oil, and makeup leaving your skin clean, smooth, and refreshed. The heating mode function can loosen thick skincare, open the pores enhancing blood flow and promote its absorption quicker and easier into your skin. Gently massage the product with skincare all over your face and neck for younger looking skin. Daily massage with vibration can also help firm and prevent sagging skin.

/product features/

- A sun-shaped metal face with 8 vibration levels for large contact on the skin's surface.
- 10,000 V-sonic pulsations per minute reach deeper into pores and remove all dirt, oil, makeup residue, and more.
- 40°C metal face promotes the absorption of skincare products.
- Food grade silicone brush hair diameter of 0.5 mm.
- IPX7 waterproof design, safe to use in the shower.



/product specifications & content/


- **Material:** Aluminum , Silica Gel, ABS
- **Input Voltage:** DC 5V/1A
- **Rated power:** 2W(Max)
- **Lithium Battery:** 1000mAh
- **Charging time:** 4.5hrs
- **Adjustment:** 8 modes
- **Waterproof rate:** IPX7
- **Main function:** 40°C/104°F warm, sonic vibration
- **Key features:** Cleansing/ Lifting / Rejuvenating
- **Certificate:** ISO 9001
- **Size:** 74 X 71 x 32 mm
- **Product weight:** 140 g

*Due to continuous improvement, the above specifications are subject to change without prior notice .

/product usage/

- Wet your face and device, apply cleanser to your face or on the silicone bristles. Applying cleanser directly to the device will create more bubbles and your device will slide smoother on the face.
- Press the power button and hold it for 2 seconds to turn on the cleansing function/press and hold to turn off.
- Press the power button 2 times to turn on heating mode for skincare absorption/ press and hold to turn the device off.
- Press + and - to increase or decrease the massaging level.

*For skin tightening and enhancing blood flow, apply facial oil, treatment serum, or cream and use heating mode to massage your face as shown.



/product care/

Thoroughly wash your device with soap and water after each use. Allow to air dry or pat dry with a lint free cloth.

Charging: A full charge can normally take up to 4.5 hours and can be used for 1 month or 60 uses per charge. Recharge your device when you feel the vibration weaken, simply connect your charging cord to the charging port on the bottom of the device and plug it into any USB port adapter. Disconnect the cord once the device is fully charged and before trying to use it, do not use the product while it is charging to avoid electric shock.

Warning

To reduce the risk of burns, electric shock, fire, or injuries, please:

- Supervise children or physically challenged persons when this device is being used.
- Use this product properly as described.
- Keep the cord away from water and heated surfaces.
- Make sure the device and charging cord are dry and in a dry area while charging.
- Charging while in contact with water may cause irreparable damage to your device.
- Do not use if the charging cable or device is damaged from being dropped, or dropped into water while charging.
- Do not place or store the device where it can fall or be pulled into water or other liquid.
- Do not charge the device near water or other liquid.
- Do not touch or charge device, or plug that has fallen into water, unplug immediately.

Warranty Coverage: One year from the original date of purchase.

- One year warranted against the defects in material and workmanship. If there is a defect in the product which is covered by this limited warranty, we agree to exchange the product with a new equivalent product.
- This warranty does not cover the damage due to normal usage, incidents, or accidents such as dropping, misuse, or neglect of the product.
- Limitation: This warranty is limited and for the original end user only or authorized distributor. To obtain this warranty, users are required to provide proof of purchase with a dated receipt or a warranty card with date. this warranty does not apply for any other reason except normal use (*normal use means ordinary consumer use under normal home conditions and follows all the instruction manual attached with this product).

Disclaimer: Please use the product as instructed, Mavian will not assume any responsibility or liability for any direct, indirect, incidental, special, or consequential damages or injuries arising from the direct or indirect use of this product, whether due to an electrical issue or otherwise. Users of this device will do so at their own risk. Specifications are subject to improvements or change.

Thank you for choosing Mavian™ to make your home facial treatment the same as a spa.



MAVIAN™

Sonic Facial Cleansing Brush

/instructions manual/